

# Product data sheet

Insert without symbol, translucent



Reference number

33 GN

**Insert without symbol, translucent**

for rockers CD 590 KO .. and CD 590 NAKO ..  
 for ref.-no.: 5560 KO, 5561 KO, 5560 KO WW and 5561 KO WW  
 for switches with indicator light and push-buttons in design range WG 800  
 for switches with indicator light and push-buttons in design range WG 600  
 for switches with indicator light and push-buttons ref.-no.: 602 KOA .., 631 A .., 634 A ..,  
 633 A ..  
 for push-buttons ref.-no.: 331 A, 333 A

**Colour:**  
 green