

# Schede tecniche di Prodotto

Sensore sole-vento



<b>Numero di riferimento</b>	
AR 04	
<b>Sunlight / wind sensor</b>	
for connection to awning control "AeroTec 04", ref.-no.: AT 04 WW The wind sensor should be fitted to the roof or house wall. It must be installed at a position suitable for wind intensity measurements. Do not install at the side sheltered from the wind.	
Ensure that no shadows (e.g. from a mast, tower, etc.) and no light reflections fall on the brightness sensor.	
<b>Dati tecnici</b>	
Grado di protezione:	IP 43